

BIO-METRIC DEVICE CONFIGURATION STEPS

Bio Metric Device Specification

NITGEN bio metric solutions

Name : Hamster DX

Model : HFDU06 17431HM 1292 DC 5V 120mA

Vendor Contact Number : 8884657565 for Bio metric device

Step 1: Install Device Driver.

Step 2: After Installation, Download the dll file from below URL

<https://exm.campusuite.in/Biometricfiles/system32/NBioBSPCOM.dll> and save the files to C:/window/System32

Step 3: Next, Download the dll file from below URL

<https://exm.campusuite.in/Biometricfiles/SySWOW64/NBioBSPCOM.dll> and save the Files to C/window/Syswow64

Step 4: Then, Go to Programs→run→cmd→Right Click and select run as Administrator and command prompt will appear and then Execute the Given below commands

Command1: cd.. (cd double dot Press enter key) repeat the same step until get C:\> in the command prompt

Command2: cd:\> cd windows (Press enter key)

Command3: cd:\windows> cd system32 (Press enter key)

Command4: cd:\windows\system32> regsvr32 NBioBSPCOM.dll (Press enter key and you will get Successful Message)

Step 5: Go to Programs→run→cmd→Right Click and select run as Administrator and command prompt will appear and then Execute the Given below commands

Command1: cd.. (cd double dot Press enter key) repeat the same step until get C:\> in the command prompt
Command2: cd:\> cd windows (Press enter key)

Command3: cd:\windows> cd SysWOW64 (Press enter key)

Command4: cd:\windows\SysWOW64> regsvr32 NBioBSPCOM.dll (Press enter key and you will get Successful Message)

Step 6: Go to Internet Explorer browser → Settings → Internet Options

Select Internet (1st Icon under security tab) →Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok

Select Local Internet (2nd Icon under security tab) → Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok

Select Trusted Site (3rd Icon under security tab) → Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok

Select Restricted Site (4th Icon under security tab) → Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok